

**TSTOWER FOR LATTICED  
GUYED MASTS**

**STRUCTURAL ANALYSIS SOFTWARE  
FOR COMMUNICATION TOWERS**


**USER'S MANUAL**

BY

*JOHN WAHBA, PH.D., P.ENG., P.E.*

*MATTHEW MALINOWSKI, P.ENG.*

[WWW.TOWERSFT.COM](http://WWW.TOWERSFT.COM)



# TABLE OF CONTENTS

<b>Chapter 1 INTRODUCTION .....</b>	<b>1—1</b>
<b>HARDWARE REQUIRMENTS .....</b>	<b>1—1</b>
<b>INSTALLING TSTOWER .....</b>	<b>1—1</b>
<b>DISCLAIMER.....</b>	<b>1—2</b>
<b>Chapter 2 INPUT .....</b>	<b>2-1</b>
START THE PROGRAM .....	2-2
PROJECT DEFINITION .....	2-3
GEOMETRY DEFINITION .....	2-4
ANTENNAS DEFINITION .....	2-10
Antenna Type: .....	2-20
POINT LOADS DEFINITION .....	2-23
TRANSMISSION LINES DEFINITION .....	2-25
Transmission Line Type: .....	2-26
LADDER DEFINITION.....	2-27
Steel Section Type:.....	2-28
<b>Chapter 3 ANALYSIS .....</b>	<b>3-1</b>
<b>CODE DATA.....</b>	<b>3-1</b>
Wind Loads.....	3-1
a) TIA/EIA 222-F.....	3-1
b) EIA 222-G (Draft).....	3-2
c) CSA S37-94 .....	3-4
d) CSA S37-01 .....	3-6
<b>ANALYSIS THEORY .....</b>	<b>3-7</b>
Wind Loads Calculations .....	3-7
Analysis and Capacities .....	3-7
Calculation Parameters .....	3-8
Material Data .....	3-9
<b>Chapter 4 RESULTS.....</b>	<b>4-1</b>
<b>Preliminary Results.....</b>	<b>4-1</b>
Wind Pressure .....	4-1
Wind Area .....	4-2
Appurtenances Uniformly Distributed Loads (UDL) .....	4-3
Appurtenances Concentrated Loads (UDL).....	4-4
<b>Final Results.....</b>	<b>4-6</b>
Legs.....	4-6
Diagonals .....	4-8
Results Summary .....	4-10
Foundations.....	4-11
Tower Displacements.....	4-12
Antenna Displacements .....	4-13
<b>Printout.....</b>	<b>4-15</b>
<b>Export Profile .....</b>	<b>4-16</b>

<b>Chapter 5 DATABASE MANAGEMENT.....</b>	<b>5-1</b>
Antennas Database.....	5-1
Non-Dish Antenna Manufacturers.....	5-2
Mounts.....	5-5
Antenna Mounts.....	5-5
Guys Database.....	5-5
Database Setup.....	5-8

## Chapter 1 INTRODUCTION

*TSTower* is a general computer program for the analysis and design of latticed guyed masts. Towers can either have triangular or square cross sections. The program will solve using the American codes TIA/EIA 222-F, TIA/222-G and the Canadian equivalent CSA S37-94 and CSA S37-01. Load generation, capacity assessments follow the applicable codes, and analysis is based on a three-dimensional beam model.

The program analyzes the tower for all specified wind, ice loads and Earthquake loads and determines the capacity of the members. The results are displayed graphically on the screen. This allows the designer to visually check the adequacy of the design and quickly make adjustments to achieve the optimum solution. The program allows for a full printout or a summary printout of the results. A graphical printout of the profile is also available.

### **HARDWARE REQUIRMENTS**

The following minimum system requirements to run TSTower:

- An IBM compatible PC equipped with a Pentium processor running under Windows 2000, or XP
- 50 MB free disk space
- 128 MB RAM
- 14 inch SVGA monitor with (800 x 600 min resolution)
- A pointing device, a mouse or graphical tablet configured to work under windows.
- An optional printer that is set from windows

### **INSTALLING TSTOWER**

The TSTower installation is initiated from windows. From start menu choose run, and choose file setup.exe

The setup program will create a TSTower directory on the hard drive at a location designated by the user. The user may change the name of the folder in which the program will copy all necessary files required to run TSTower.

Choose the folder name and click OK, the installation program will copy all necessary files into the different directories of your system. Follow the program instructions and place the subsequent disks into the disk drive.

At the end of the installation the program will notify you that the installation was completed successfully. Refer to the purchasers agreement regarding the number of authorized users allowed to run the program.

### **DISCLAIMER**

Extensive care has been taken during the development and testing of TSTower program to ensure that both the source code and the underlying engineering principles comply with standard engineering practice. Should any discrepancies or possible program errors occur, please notify TowerSoft immediately.

TOWERSOFT DISCLAIMS ALL WARRANTIES IMPLIED OR OTHERWISE WITH REGARDS TO THE SOFTWARE. BY USING THE SOFTWARE, THE USER AGREES THAT NEITHER TOWERSOFT NOR ITS EMPLOYEES SHALL BE LIABLE FOR ANY LOSS, DAMAGE, OR EXPENSE OF ANY KIND WHICH IS CAUSED DIRECTLY OR INDIRECTLY BY THE USE, PERFORMANCE, MAINTAINANCE, SERVICE OR CONDITION OF THE SOFTWARE. IN NO EVENT WILL TOWERSOFT BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGE RESULTING FROM USE OF THIS SOFTWARE.

User's comments and suggestions are welcomed. Please forward all your comments to [support@towersft.com](mailto:support@towersft.com).

## Chapter 2 INPUT


*TSTower* is an analysis software program. The user inputs all the necessary information required to perform the analysis, the finite element program is run, and the results are shown in a graphical format on the screen.

For design purpose, the user decides on a tentative geometry and performs an analysis. The user examines the results of the preliminary selection and modifies any of the design parameters before reanalyzing the structure. Using successive runs, the user can quickly arrive at an optimum solution. The designer makes the choices, interprets the output and has full control on the design process.

This Chapter illustrates how *TSTower* works by explaining the input screens. The input values and screens are shown on the figures in this chapter utilizing an example. This example may not use all the features of the software, however it gives the user a quick introduction to the main features and the use of the program. Features available in the program that are not used for this example are explained in the context.

## START THE PROGRAM

When TSTower starts, the main screen shows a blank page. The user selects a structure type from the Structure menu. The three options are either tubular SS, latticed SS, or guyed mast structures.




Note the status bar at the bottom of the windows showing the following data in order:

- 1- The current mode of units (metric or US Customary)
- 2- The applicable code of design (CSA S37-01, CSA S37-94, EIA 222-F, ANSI/TIA 222-G)


- 3- The problem file name, and path
- 4- Structure type (Tubular , Latticed or Guyed Mast)

Select **Options** from the main menu and from the list choose the required code and the system of units.



## PROJECT DEFINITION

Select **Project Data** from the **Options** menu. Type in any identification data required as shown.


A screenshot of the 'Project Data' dialog box. It contains several text input fields: 'Customer' (TowerSoft), 'Site ID' (A0001), 'Location' (Mississauga-ON-CANADA), 'Project' (03-00-001), 'Revision' (0), and 'Engineer' (Any Engineer). At the bottom, there are 'OK' and 'Cancel' buttons.

To add data to any box, move the cursor into the box, click inside the box and type in the data using the keyboard. To change any existing data in an edit

box, delete the entry using the <Del> key or the <Backspace> key. Alternatively, highlight the existing characters by pressing and dragging the left mouse button, then type over the existing entry. This is a standard Windows feature.

### GEOMETRY DEFINITION


Select **Structure/Guyed Mast/Mast** from the main menu, this will show the Geometry Definition Window. Initially the window will show default geometry data and the user changes that to the required parameters.



In this window the user inputs the total height, top and bottom widths of the tower, typical section height and clicks on the Section Generator button. This will create the general outline of the tower sections based on the selected typical section height. The user can model multiple slopes on the tower or straight sections for example on the top of the tower by locking top or bottom width of a selected section. From this screen, the user can add sections to the top or bottom of the tower, delete sections at the top of the tower or delete a selected number of sections.

Note that the defaults of the sections generation can be edited from the Defaults button. The user can also switch from Tower View or zoom to Section View to see an enlarged view of the selected section.

The user can also utilize the import and export section functionality to save or retrieve a section from the user-defined database of standard sections.



On the next Tab "Panel Data" the user can define the number, type, height of panels for the selected section. From the section column, other sections can be selected for Panel definition. Also on the same window the user can modify selected panels, change heights for different panels, redefine section panels and or copy section panels to other section(s).

Sec. No.	Pan. No.	Type	Description	Steel Grade	Conn. Type	No. of Bolts	Bolt Size (in)	Bolt Grade	End Dist. (in)	Edge Dist. (in)	Gusset Thick. (in)
1	1	Leg	SR 4	A36	Tension	1	0.625	A325X	n/a	n/a	n/a
		Diag	L4x4x3/8	A36	Bolted	1	0.625	A325X	0.938	0.938	0.394

From the Member Geometry Screen, the user defines the member sizes, steel grades, connection type, number of bolts, bolt size, bolt grade, end distance, edge distance and gusset thickness. The following is a definition of the different fields:

Formatted: Bullets and Numbering

**Member Description:** By double clicking the user can select another member from the same type of members (Angles, Tubes, Solid Rounds, etc.). By left clicking the Member Data form will open and allow the user to change the member type or size.

**Steel Grade or Bolt Grade:** By double clicking the user selects from a drop down list of available grades. The user can add or edit different grades from the Database Management Menu. By left clicking the yield and ultimate values of the selected grade are displayed. Note that for bolt grades, the threads included or excluded from the shear plane are available.

**Connection Type:** By double clicking the user can select connection type. For legs the user selects from tension, single shear or double shear. For other members the selections are either welded to bolted.

Number of Bolts: the user selects or types in the number of bolts for the connection.

End distance: defined as distance from the center of bolt to the end of the member along the axis of the member (force).

Edge Distance: defined as the distance from the center of bolt to the edge of the member (normal to the line of force).

Gusset Thickness: the gusset thickness for connection of legs to other members. For leg angles, the thickness of the leg is assumed to be the gusset thickness but can be over written by the user.

Note that the click button at the bottom allows the user to select either identical or different members for each of the panels of the section.

**Latticed Tower Geometry**

Tower Data

Structure Height: 200.000 (ft) | Top Width: 42.00 (in) | No. of Sections: 10  
 Bot. Width: 42.00 (in) | Total Height: 200.000 (ft)  
 Typical Section Height: 20.000 (ft) | Cross-Section: Triangular

Section Generator | Restraints at Base

Section Geometry | Panel Geometry | Member Geometry | **Member Capacities** | Section Property

Sec. No.	Pan. No.	Member Type	Description	Length (ft)	kL/R	User Def. kL/R	Comp. Capacity (Kips)	Tens. Capacity (Kips)	Bearing Capacity (Kips)	Block Shear Capacity (Kips)	Bolt Capacity (Kips)	Critical Comp. Capacity (Kips)
1	1	Leg	SR 2	4.00	96.00	No	68.08	141.49	n/a	n/a	54.49	68.08
		Diag	SR 0 7/8	5.32	104.01	No	10.41	19.47	n/a	n/a	n/a	10.41

Defaults | Import Section | Export Section | OK | Tower View | Section View

The Member Capacities tab displays the following data:

- Section number (from bottom to top)
- Panel number (From bottom to top)

- Member Description
- Length of member (m or ft)
- KL/R (program calculated effective slenderness ratio - can be overwritten by User)
- User Def. kL/R (No) means kL/R calculated by program, (Yes) means that the User has overwritten the kL/r and the Users entry will be used for capacities
  
- Compression Capacity (kN or Kips)
- Tension Capacity (kN or Kips)
- Bearing Capacity (kN or Kips)
- Block Shear Capacity (kN or Kips)
- Bolt Capacity (kN or Kips)
- Critical (Governing) Compression Capacity (kN or Kips)
- Critical (Governing) Tension Capacity (kN or Kips)

### GUY SYSTEM CONFIGURATION

Select **Structure/Guyed Mast/Mast** from the main menu, this will show the Guy System Configuration Window.

**Guy System Configuration**

Guy Levels Sizes      Guy Details      Torsion Resistors

Lev. #	Elevation (ft)	Guy Size	Breaking Strength (Kips)	Efficiency Factor (%)	Radius (ft)	No. of Guys	Torsion Resistor	kL/r of Span
1	75.000	EH 7/16	20.80	100.00	240.000	3	(None)	40.08
2	135.000	EH 7/16	20.80	100.00	240.000	3	(None)	32.07
3	205.000	EH 1/2	26.90	100.00	240.000	3	(None)	37.41
4	275.000	EH 1/2	26.90	100.00	240.000	6	Truss Type	37.41

Formatted: Bullets and Numbering

The following is a definition of the different fields:

Elevation: Distance from base of the tower to guy attachment at mast

Guy Size: Selected from Database table

Breaking Strength: Read-only field – matching selected guy size with Breaking Strength from Database table

Efficiency Factor: By default 100%. Users should determine if lesser efficiency factor should be used depending on guy hardware

Radius: Distance from the center of the mast to guy attachment at anchor

Number of Guys: Default (minimum) 3 for triangular towers and 4 for square towers at given guy level. For Torsion Resisting (Torque Arm) systems the number of guys is twice the default (6 for triangular and 8 for square towers).

KL/R of Span: Span slenderness calculated by the program.

From the Guy System Configuration Screen, the user defines the guy level' elevation, guy size, guy efficiency factor, guy radius, number of guys and torsion resistor type (if applicable).


Clicking on "Add Guy Level" button creates a new guy level. The choice of elevations in form of "drop-down" box will appear in cell of "Elevation" column. Please, note that the program chooses the available elevations as nodes (panel points). You may, however, type desired elevation directly in the cell instead of selecting it from the drop-down box.

A guy level can be deleted by selecting (setting focus) at given row and by clicking on "Remove Guy Level" button.

Guy size and type can be determined by clicking in the cell of column "Guy Size". A drop-down box allowing selection of any guy from available Guys database appears. Breaking Strength (read only) appears in the column adjacent to Guy Size column.

Torsion Resistor type (applicable only when the number of guys is two times more than the number of tower legs – 6 guys for triangular tower and 8 guys for square tower) can be selected from drop-down box as "Truss Type" or "Beam Type". Please note that the selection of 6 guys for triangular and 8 guys for square towers with guys attached symmetrically to torque arms, even without selecting Torsion Resistor, will still be treated by the analysis as a torsion resisting system. The difference of choosing explicitly a torsion resistor will make the program to consider the Torsion Resistor members for loading (both wind load and their weights) and will show in the output the assessment of the Torsion Resistor members.

Please note that the values contained in the tab "Guy Levels, Sizes" of the form are general and some of them (such as Guy Sizes and Radiuses) may differ for each guy at a given level. More detailed definitions of the guys' parameters for a given level are maintained in tab "Guy Details" of the form.



The following is a definition of the different fields:

← - - - Formatted: Bullets and Numbering

**Guy Azimuth:** Azimuth of guy anchor measured from tower's North (triangular towers have North going through the apex leg and for square towers the North line is perpendicular to the face).


**Anchor Elevation:** Vertical Distance of the anchor from the tower's base. Positive elevations above the base, negative below the base.

**Attachment Radius:** Distance from the center of the tower to the attachment of the guy at mast (for Torsion Resistors to the attachment of the guy to the arm).

**Attachment Azimuth:** Angle between the tower's North and line going through the guy's attachment.

**Initial Tension:** By default 10% of the Breaking strength but may be overwritten by User.

Torsion Resistor Geometry and members:



The following is a definition of the different fields:

← Formatted: Bullets and Numbering

For Torsion Resistor Geometry and Bracing type (for Truss Type):

Upper Arm Attach. Elevation: Elevation of the attachment of the upper arm of the Torsion Resistor to the mast

Lower Arm Attach. Elevation: Elevation of the attachment of the lower arm of the Torsion Resistor to the mast

Upper Truss Bracing: Available choices are None, Single Braced, X-Braced

Lower Truss Bracing: Available choices are None, Single Braced, X-Braced

Vertical Truss Bracing: Available choices are None, Diagonal, Diagonal + Horizontal

Each of the above-mentioned bracings, if selected, will be shown in Selected View (Side, Top and Bottom Views) and the default bracing members will be added to the grid below (Member Geometry tab).

For Member Geometry:

Member Size: the cell in column "Description" serves to select the member size and type from Steel Database tables. Double clicking on selected cell allows to re-select member from the same member type table (e.g. equal angles). Right hand clicking on the selected cell allows to choose any table of steel shapes and to select a member from such table.

Steel Grade or Bolt Grade: By double clicking the user selects from a drop down list of available grades. The user can add or edit different grades from the Database Management Menu. By left clicking the yield and ultimate values of the selected grade are displayed. Note that for bolt grades, the threads included or excluded from the shear plane are available.

Connection Type: By double clicking the user can select connection type. For arms the user selects from tension or bolted. For other members the selections are either welded to bolted.


Number of Bolts: the user selects or types in the number of bolts for the connection.

End distance: defined as distance from the center of bolt to the end of the member along the axis of the member (force).

Edge Distance: defined as the distance from the center of bolt to the edge of the member (normal to the line of force).


Gusset Thickness: the gusset thickness for connection of arms to other members. For leg angles, the thickness of the leg is assumed to be the gusset thickness but can be over written by the user.

Bolt Spacing: defined as the distance between the centers of adjacent bolts (normal to the line of force).



The Member Capacities tab displays the following data:

- Member Type
- Member Description
- Length of member (m or ft)
- kL/R (calculated effective slenderness ratio) but User can directly overwrite this value
- User Def. kL/R (No) means kL/R calculated by program, (Yes) means that the User has overwritten the kL/r and the Users entry will be used for capacities
- Compression Capacity (kN or Kips)
- Tension Capacity (kN or Kips)
- Bearing Capacity (kN or Kips)
- Block Shear Capacity (kN or Kips)
- Bolt Capacity (kN or Kips)
- Critical (Governing) Compression Capacity (kN or Kips)
- Critical (Governing) Tension Capacity (kN or Kips)



It is recommended that the User sets up Torsion Resistor Defaults before working with the details of the members.

The form above illustrates the General properties of the members.

The next tab, "Members", allows declaring default member types, steel grades, connections, number of bolts, bolt sizes and grades. Separate selections can be made for beam arm, truss arm and for truss bracing members.

When defaults are defined the User may choose to:

Save in File - that will keep the current selection until the next change and saving - Button "OK & Save in File",

Save for the current tower only - Button "OK",

Cancel - to ignore all selections - Button "Cancel".


Beam Arm	Truss Arm	Truss Bracing
Description: C6x13	Description: L4x4x3/8	Description: L4x4x3/8
Steel Grade: A36	Steel Grade: A36	Steel Grade: A36
Conn. Type: Tension	Conn. Type: Bolted	Conn. Type: Bolted
Bolts Num: 2	Bolts Num: 2	Bolts Num: 1
Bolts Size: 0.625	Bolts Size: 0.625	Bolts Size: 0.625
Bolts Grade: A325X	Bolts Grade: A325X	Bolts Grade: A325X

### Balancing Initial Tension

The variations in anchor radiuses and elevations at particular guy level may cause significant lack of balance of the resultant horizontal force acting at this guy level. For newly designed towers and for proposed modifications, reinforcing and maintenance of existing towers it is recommended to bring the guy system to the balanced state, where the resultant horizontal is equal or close to zero.


Click on "Balance Initial Tension" button on the form "Guy System Configuration", tab "Guy Levels, Sizes".

Following screen "Balance Initial Tension" will show for each guy level the value of Horizontal Resultant Force.



In case the horizontal resultants are considered too large (need for balancing) please click on "Adjust unbalanced Level" button for a selected guy level.

Following screen appears. You may choose to execute the balancing with Initial Tension kept "as is" for selected guy, to execute the balancing without any preference or to cancel the balancing.



Setting the Restraints of the mast at base

Click on "Restraints at Base" button

**Latticed Tower Geometry**

Tower Data

Structure Height: 300.000 (ft) | Top Width: 55.00 (in) | No. of Sections: 15  
 Bot. Width: 55.00 (in) | Total Height: 300.000 (ft)  
 Typical Section Height: 20.000 (ft) | Cross-Section: Triangular

Section Generator | **Restraints at Base**

Section Geometry | Panel Geometry | Member Geometry | Member Capacities | Section Property

Sect. No.	Description	Height (ft)	Bot. Elev. (ft)	Bot. Width (in)	Locked Bot. Width	Top Width (in)	Locked Top Width	No. of Panels	Mass (lbs)	Database Mass (lbs)
7	S7	20.000	120.000	55.00	U	55.00	U	4	1378.1	0.0
6	S6	20.000	100.000	55.00	U	55.00	U	4	1378.1	0.0
5	S5	20.000	80.000	55.00	U	55.00	U	4	1378.1	0.0
4	S4	20.000	60.000	55.00	U	55.00	U	4	1378.1	0.0
3	S3	20.000	40.000	55.00	U	55.00	U	4	1378.1	0.0
2	S2	20.000	20.000	55.00	U	55.00	U	4	1378.1	0.0
1	S1	20.000	0.000	55.00	U	55.00	U	4	1378.1	0.0

Add section at top | Add section at bottom | Delete section at top | Delete section

Defaults | Import Section | Export Section | OK | Tower View | Section View

And select the restraints conditions:

**Mast Restraints at Base**

Deflection in North - South direction  **Restrained**

Deflection in East - West direction  **Restrained**

Downward Deflection  **Restrained**

Rotation in North - South direction  **No Restraint**


Rotation in East - West direction  **No Restraint**

Twist  **Restrained**

OK

**ANTENNAS DEFINITION**

From the main menu choose **Appurtenance** and then select **Antennas**, the following window is displayed.



In this window the tower elevation is shown along with the plan cross-section at the marked antenna. To add a new antenna select **New** and a blank line with an antenna type (none) is shown. The user inputs the following data as defined below:

- **Elevation:** Elevation of the center of the antenna marked from the bottom of the tower and shown in meters or ft.
- **Antenna Type:** Type of antenna and can be chosen from the antennas database available. To choose an antenna click on this field and an antenna type window will be displayed and the required type and size is specified.

- **Antenna Azimuth:** Antenna beam azimuth measured from the North. The tower azimuth from north is specified at the bottom of the tower (specified in degrees).
- **Radius:** Radius is measured from the tower center to the mounting point of the antenna (m or ft.). Also, note that the tower radius at that elevation is shown for guidance on the section drawing.
- **Mount Type:** Type of antenna mount and can be chosen from the database available. To choose a mount click on this field to select from the database.
- **Mounting Azimuth:** angle between the tower's north and the antenna radius measured in the clockwise direction.
- **Tx-Line Type:** Type of transmission lines and quantity associated with that antenna and can be chosen from a database available.

### Antenna Type:

Click on type in the antenna table and the following window is displayed and from which the antenna type and size is specified.

The screenshot shows a dialog box titled "Antenna Type" with two tabs: "Microwave" and "Other". The "Microwave" tab is selected. The dialog contains the following fields and controls:

- Dish Type:** A dropdown menu set to "Shielded".
- Dish Size:** A dropdown menu set to "HP4".
- Frequency (GHz):** A dropdown menu set to "6".
- Allowable Tilt/Twist (deg):** A text input field containing "2.21".
- Radome:** Two radio buttons, "Yes" (selected) and "No".
- Allowable signal loss:** Two radio buttons, "3 db" and "10 db" (selected).
- Buttons:** "OK" and "Cancel" buttons at the bottom.

For microwave dishes available in the database the following dish types and sizes are available:

Shielded	(2, 4, 6, 8, 10, 12, 15 ft.)
Focal plane	(4, 6, 8, 10, 12 ft. – with or without radome)
Standard	(2, 4, 6, 8, 10, 12 ft. – with or without radome)
Grid	(4, 6, 8, 10, 12, 15 ft.)
GRIDPAK	(4, 6, 8, 10, 12, 13 ft.)

Also, for microwave antennas the allowable Tilt/Twist is calculated by the program as a function of frequency, dish diameter and allowable signal degradation (3 db or 10 db) based on the following formula:

a) For a parabolic reflector with an allowable 10dB signal degradation:

$$\theta = \frac{C_{10}}{D \alpha}$$

b) For a parabolic reflector with an allowable 3dB signal degradation:

$$\theta = \frac{C_3}{D \alpha}$$

where:

$\theta$  = twist or sway limit, degrees

$C_{10}$  = 53.1 GHz.ft.deg [16.2 GHz.m.deg]


$C_3$  = 31.0 GHz.ft.deg [9.45 GHz.m.deg]

D = Diameter of dish, ft [m]

$\alpha$  = Dish Frequency, GHz.

For "Other" (Non-Dish Antennas) a variety of Antennas, organized by manufacturers is available from the database.

Following screen is displayed when the Tab "Other" is clicked.



The data shown includes all parameters of these antennas necessary for the program to calculate wind loads and weight effects.

The User may add any type of Non-Dish Antenna to the database -using the "Database Management" option from the main menu. Refer to Database Management Chapter for details.


After specifying an antenna, the user may wish to copy it by highlighting the specific line and click on **select** and then on **Copy**. A new line of antenna will be displayed and the user may edit that line. A similar procedure is used to delete an antenna.

Loads are calculated for microwave dishes as per Andrew's catalogue number 36. Also load calculations for wind loads under different directions are based on EIA-222-F tables.

Also, from this window the user can define the TX-lines type and number that are used for this antenna.

## POINT LOADS DEFINITION

From the main menu choose **Appurtenance** and then select **Point Loads**, the following window is displayed.




In this window the pole elevation is shown along with the plan cross-section at the point load elevation. To add a new point load select **New** and input line with zero values is shown. The user inputs the following data as defined below:

- **Description:** Text description of the point load. This description will be displayed on the design profile. If the default description is not over written no description is displayed on the profile.

- **Elevation:** Elevation from the bottom of the tower to the center of the applied load (m or ft.)
- **Azimuth:** angle between the north and the point load radius measured in the clockwise direction (specified in degrees).
- **Radius:** Radius is measured from the tower center to the point load (m or ft.). Also, note that the tower radius at that elevation is shown for guidance on the section drawing.
- **Wind Area (Bare):** Bare wind area of the load (antenna) multiplied by the appropriate force coefficient or drag factor depending on the shape of the appurtenance (m<sup>2</sup> or ft<sup>2</sup>).
- **Wind Area (Iced):** Iced wind area of the load (antenna) multiplied by the appropriate force coefficient or drag factor depending on the shape of the appurtenance and the ice accretion (m<sup>2</sup> or ft<sup>2</sup>).
- **Weight (Bare):** Bare weight of the load (kN or kips)
- **Weight (Iced):** weight of the load including ice (kN or kips)
- **Comments:** A comments field that does not get displayed on the profile.

**TRANSMISSION LINES DEFINITION**

From the main menu choose **Appurtenance** and then select **Tx-lines**, the following window is displayed.



In this window the tower elevation is shown along with the tower cross-section at the bottom of the Tx-line. To add a new line or group of lines select **New** and a blank line with a line type (none) is shown. The user inputs the following data as defined below:

- **Bottom Elevation:** Elevation of the bottom of the lines (m or ft.)
- **Top Elevation:** Elevation of the top of the lines (m or ft.), please note that the length of TX line located above the tower top will be ignored by the program for loading.

- **Type:** Type of lines and can be chosen from the tx-lines database available. To choose line type click on this field and the required type and size can be specified as explained in the sequel.
- **No of lines.:** Number of lines having the same properties shown on that line
- **Azimuth:** Group of lines azimuth (specified in degrees).
- **Radius:** Radius is measured from the pole center to the center of the lines group (m or ft.).
- **Orient.:** angle between the pole's north and the lines group radius measured in the clockwise direction.
- **No of Shielded Lines:** For shielded lines (e.g. inside the pole) only gravity loads are considered.

### **Transmission Line Type:**

Click on type in the tx-lines table and the following window is displayed and from which the tx-lines type and size is specified.

The following Transmission Line types are available:


Air-Dielectric  
Foam-Dielectric  
Elliptical Waveguide  
Circular Waveguide  
Rectangular Waveguide

Different sizes can be chosen from the description field and the actual size for the chosen lines is displayed in the size field (mm or in.).

Data for transmission lines mechanical properties are based on Andrew's catalogue number 36.

LADDER DEFINITION

From the main menu choose **Appurtenance** and then select **Ladders**, the following window is displayed.



In this window the pole elevation is shown along with the plan cross-section at the bottom of the ladder. To add a new ladder select **New** and a blank line with a rail type, and rung type (none) is shown. The user inputs the following data as defined below:

- **Bottom Elevation:** Elevation of the bottom of the ladder (m or ft.)
- **Top Elevation:** Elevation of the top of the ladder (m or ft.), please note that the length of ladder, located above the tower top, will be ignored by the program for loading
- **Width:** Width of ladder rungs (mm or in.)
- **Dist.:** Distance (spacing) between rungs (mm or in.)
- **Azimuth:** ladder azimuth (specified in degrees).

- **Radius:** Radius is measured from the pole center to the center of the ladder (m or ft.).
- **Orient.:** angle between north and the ladder's center measured in the clockwise direction.
- **Rung Type:** Rung size chosen from available steel sections database for angles and solid rounds.
- **Rail Type:** Rail size chosen from available steel sections database for angles and solid rounds.

### Steel Section Type:

Click on rail type or rung type in the ladder data table and the following window is displayed, from which the steel section type and size is specified.

The screenshot shows a dialog box titled "Steel Section Type". It contains two dropdown menus: "Type" with "Solid Round" selected and "Description" with "SR 0.625" selected. At the bottom, there are "OK" and "Cancel" buttons.

The following steel sections for ladders are available:

Solid Round (SR13, SR16, SR19, SR25, SR50)  
(SR.5, SR.625, SR.75, SR1.0, SR2.0)

Angle (L51x51x6, L51x51x13)  
(2x2x1/4, 12x2x1/2)

← Formatted: Bullets and Numbering

### Chapter 3 ANALYSIS

This Chapter explains the input of the code-related data and material data. Also, the assumptions and the underlying theory of the analysis are explained in the sequel.

#### CODE DATA

##### Wind Loads

From the main menu choose **Load Cases**, and then the following window will appear depending on the design standard specified:

##### a) TIA/EIA 222-F

Having the EIA 222-F as the design code, the wind Loads window will be as shown:

**TIA/EIA-222-F-1996 Code Data**

Wind Speed	80.00	(mph)
Service Wind Speed	50.00	(mph)
Ice Thickness	0.50	(inch)
Ice Density	56.00	(pcf)
Start wind direction	0.00	(degrees)
End wind direction	330.00	(degrees)
Increment wind direction	30.00	(degrees)
Elev. above ground	0.00	(ft)
Wind pressure reduction for iced conditions	0.75	
Temp. Reduction with Ice	50.0	(Fahrenheit)
<input checked="" type="checkbox"/> Increase allowable stresses		
<input checked="" type="checkbox"/> Strength - Wind only <input checked="" type="checkbox"/> Service - Wind only		
<input checked="" type="checkbox"/> Strength - Wind and Ice <input type="checkbox"/> Service - Wind and Ice		

OK    US Counties

The input data is explained as follows:

- Wind Speed: Design wind speed for the structure (m/sec or mph).
- Service Wind Speed: for the calculation of deflections (tilt/twist) under service load conditions (m/sec or mph).
- Ice Thickness: specified ice thickness for the design of the structure depending on the location (mm or inches).
- Start Wind Direction: Starting wind directions from which the wind loads are considered.
- End wind directions: Last wind direction for which the wind loads are considered
- Increment Wind direction: Wind increment in degrees at which wind loads are calculated. For example, in the above shown example wind will be considered at the following directions (0, 30, 60, 330)
- Elevation above ground: The elevation of the structure base above ground this is used for wind loads calculations. The height factor is increased accordingly.
- Allowable stress factor: For the structural assessment of the tower, the allowable stress is increased to 1.33 as per EIA 222-F when applicable. However, the user has the option to limit the allowable stress to 1.0
- Wind pressure reduction for the case of iced conditions (default is 0.75 as per code).
- Options to mark the analysis loading cases for wind only or for combined case of wind and ice under strength conditions and service conditions.

**b) ANSI/TIA-222-G-2005**

Having the TIA-222-G as the design code, the Wind Loads window will be displayed as shown:

**ANSI/TIA-222-G Code Data**

Wind Speed (V)	100.00	(mph)	
Wind Speed with Ice (Vi)	40.00	(mph)	
Serviceability Wind Speed	60.00	(mph)	
Ice Thickness (ti)	0.50	(inch)	Ice Density 56.00 (pcf)
Start wind direction	0.00	(degrees)	
End wind direction	330.00	(degrees)	
Increment wind direction	30.00	(degrees)	
Elev. above ground	0.00	(ft)	
Structure Class	2		
Exposure Category	C		
Topographic Category	1		Gust Effect Factor (Gh) 0.85
Temperature Reduction with Ice	50.0	(Fahrenheit)	
Survival Wind (as per Annex A - A.2.3.2)			<input type="checkbox"/>
Min. Bracing Resistance: Pr=1.5% Fs (15.6.b.)			<input type="checkbox"/>
Most Shear & Torsion: 40% min. need not apply (15.6.a.)			<input type="checkbox"/>
<input checked="" type="checkbox"/> Strength - Wind only	<input checked="" type="checkbox"/> Service - Wind only		
<input checked="" type="checkbox"/> Strength - Wind and Ice	<input type="checkbox"/> Service - Wind and Ice		
<input type="checkbox"/> Pattern Loading	<input type="checkbox"/> Earthquake Loading		

OK US Counties

The input data is explained as follows:

- Basic Wind Speed (V): 3-second gust speed for the structure (m/sec or mph).
- Wind Speed with Ice (Vi): 3-second gust speed concurrent with the design ice at 33 ft above the ground (m/sec or mph).
- Serviceability Wind Speed: for the calculation of deflections (tilt/twist) under service load conditions (m/sec or mph).
- Ice Thickness (ti): specified ice thickness for the design of the structure depending on the location (mm or inches).

- Start Wind Direction: Starting wind directions from which the wind loads are considered.
- End wind directions: Last wind direction for which the wind loads are considered
- Increment Wind direction: Wind increment in degrees at which wind loads are calculated. For example, in the above shown example wind will be considered at the following directions (0, 30, 60, 90, 120, 150, 180, 210, 240, 270, 300 and 330)
- Elevation above ground: The elevation of the structure base above ground this is used for wind loads calculations. The height factor is increased accordingly.
- Structure Class as defined in Table 2-1 of ANSI/TIA-222-G. Values are 1 through 3 with class 2 as default.
- Exposure Category as defined in clause 2.6.5.1 of ANSI/TIA-222-G. Options are Exposure B, C or D with Exposure B as default.
- Topographic Category as defined in clause 2.6.6.2 of ANSI/TIA 222-G ranging from Category 1 through 5 with Category 1 as default.

Please note that in addition to wind, wind and ice, and serviceability loading cases the program may optionally run the pattern loading as defined in Figure 3-3. The Earthquake Loading case may be analyzed as well with usage of Seismic Analysis Procedure Method 1 as defined by ANSI/TIA-222-G.

**c) CSA S37-94**

Having the CSA S37-94 as the design code, the wind Loads window will be displayed as shown:

**CSA-S37 Code Data**

Wind Pressure: 600.00 (Pa)

Ice Thickness: 25.00 (mm)      Ice Density: 900.00 (kg/m<sup>3</sup>)

Importance Factor: 1.00

Serviceability Factor: 1.00

Start wind direction: 0.00 (degrees)

End wind direction: 330.00 (degrees)

Increment wind direction: 30.00 (degrees)

Elev. above ground: 0.00 (m)

Temp. Reduction with Ice: 10.0 (Celsius)

Hydro-Quebec Coefficients?  
Hydro-Quebec Ce and Cg values

Strength - Wind only       Serviceability - Wind only

Strength - Wind and Ice       Serviceability - Wind and Ice

Site Specific Wind

Site Specific Wind Coefficients		
	0 - z	> z
Coefficient a1:	0.0000	0.0000
Coefficient a2:	0.00000	0.00000
Coefficient a3:	0.000	0.000
Coefficient Zh:	0.000	0.000
Coefficient Z01:	0.000	0.000
Coefficient V01:	0.000	0.000
Height (z) for 2nd curve: (m)	0.00	

OK

The data for which is explained as follows:

- Wind Pressure: Reference wind pressure (q) as per CSA S37-94
- Ice thickness: Radial ice thickness for the design
- Importance factor: Importance factor as per S37-94
- Serviceability factor: Serviceability factor for service load conditions as per S37-94
- Start Wind Direction: Starting wind directions from which the wind loads are considered.
- End wind directions: Last wind direction for which the wind loads are considered
- Increment Wind direction: Wind increment in degrees at which wind loads are calculated. For example, in the above shown window, wind will be considered only from 0 degrees.

- Elevation above ground: The elevation of the structure base above ground. This is used for wind loads calculations.
- Options to mark the analysis loading cases for wind only or for combined case of wind and ice under strength conditions and service conditions.
- Option to use site specific wind data

**d) CSA S37-01**

Having the CSA S37-01 as the design code, the wind Loads window will be displayed as shown:

**CSA-S37 Code Data**

Wind Pressure: 600.00 (Pa)

Ice Thickness: 25.00 (mm)      Ice Density: 900.00 (kg/m<sup>3</sup>)

Importance Factor: 1.00

Serviceability Factor: 1.00

Start wind direction: 0.00 (degrees)

End wind direction: 330.00 (degrees)

Increment wind direction: 30.00 (degrees)

Elev. above ground: 0.00 (m)

Temp. Reduction with Ice: 10.0 (Celsius)

Strength - Wind only       Serviceability - Wind only  
 Strength - Wind and Ice       Serviceability - Wind and Ice

Hydro-Quebec Coefficients?  
 Hydro-Quebec Ce and Cg values

Site Specific Wind

Site Specific Wind Coefficients		
	0 - z	> z
Coefficient a1:	0.0000	0.0000
Coefficient a2:	0.00000	0.00000
Coefficient a3:	0.000	0.000
Coefficient Zh:	0.000	0.000
Coefficient Z01:	0.000	0.000
Coefficient V01:	0.000	0.000
Height (z) for 2nd curve: (m)	0.00	

OK

The design parameters are as explained under S37-94.

## ANALYSIS THEORY

The analysis is based on an elastic three-dimensional beam-column where the mast is modeled as equivalent three-dimensional beam-column members supported by cables represented as cable elements. Wind load calculations and analysis are based on the following assumptions:

### Wind Loads Calculations

1. Wind is assumed horizontal and is blowing from a certain direction throughout the whole mast height.
2. Force coefficients (drag factors) are calculated as per applicable code.
3. Tx-lines declared as part of the face are considered in the force coefficient calculations of the structure. Tx-Lines as part of the face and outside shield the structural members and vice versa for lines inside the tower (that is not applied for ANSI/TIA-222-G standard). ← --- Formatted: Bullets and Numbering
4. Ice built up is considered uniform on the structure and appurtenances except for ANSI/TIA-222-G standard where the ice effect is changing in function of the height. ← --- Formatted: Bullets and Numbering
5. Wind loads considered on iced structures are reduced as per applicable code. ← --- Formatted: Bullets and Numbering
6. For wind load calculations, wind load is calculated for each section. ← --- Formatted: Bullets and Numbering
7. Loads that are offset from the tower center are applied at the tower center with the corresponding moments (torsional and bending). ← --- Formatted: Bullets and Numbering
8. Loads that extend beyond the height of the structure are applied at the top of the structure with the corresponding additional moments (torsional and bending). ← --- Formatted: Bullets and Numbering

### Analysis and Capacities


1. Each member is modeled as two-nodded three-dimensional truss elements with three degrees of freedom at each node. ← --- Formatted: Bullets and Numbering
2. Element properties are assumed constant for the full length of the member. ← --- Formatted: Bullets and Numbering

3. Uniform loads applied to the tower are distributed to each level of the section at the three or four leg points.
4. Capacities are calculated based on applicable codes and the structure is assessed for each member.

← Formatted: Bullets and Numbering

### Calculation Parameters

From the main menu, choose “setup” and select “Calculation Parameters”. In this menu, the user may change the equivalent wind area calculations for non-dish antennas and setup the shielding factor Ka for linear appurtenances (for CSA-S37 and for EIA-222-F standards).



For non-dish antennas, the user can select the calculation method for the equivalent wind area of non-symmetric antennas.

**Material Data**

Clicking on **Setup** from the main menu the material data can be defined. The user inputs the material density (lbs/ft<sup>3</sup> or kg/m<sup>3</sup>), Young's modulus (ksi or MPa) and Poisson's ratio.

**Material Data**

Density: 490.0 (lbs/ft<sup>3</sup>)

Young's Modulus: 29000.00 (ksi)

Poisson Ratio: 0.30

Weight Increment: 1.00

Note: The Weight Increment will be used to increase the dead weight of structural members in order to account for the additional hardware (bolts, nuts, washers etc.). The increment is in addition to dead weight load factors (if applicable).

OK Cancel

**Guy Rupture Analysis**

Please note, that for ANSI/TIA-222-G standard the program can perform the guy rupture analysis as per Annex E of the standard. When this option is selected from the Run menu the program shows following form:

**Select Broken Guy for Guy Rupture Analysis**

Guy	Elevation(ft)	Guy Size	Guy Azimuth (deg)
1	75.00	EH 7/16	0
1	75.00	EH 7/16	120
1	75.00	EH 7/16	240
2	135.00	EH 7/16	0
2	135.00	EH 7/16	120
2	135.00	EH 7/16	240
3	205.00	EH 1/2	0
3	205.00	EH 1/2	120
3	205.00	EH 1/2	240
4	275.00	EH 1/2	0
4	275.00	EH 1/2	0
4	275.00	EH 1/2	120
4	275.00	EH 1/2	120
4	275.00	EH 1/2	240
4	275.00	EH 1/2	240

Select Cancel

The User may select any guy elevation and any guy number at this elevation to perform this analysis.

## Analytical Engine

In addition to using the TSTower finite element analytical engine the users may select two additional programs (the User shall have the license to use these programs in order to utilize these options):

- GUYMAST by Weisman Consultants Inc.
- Robot Millenium by RoboBat

In order to run the analysis with one of these engines the User should change the analytical engine from Menu Setup/ Default Standard, Units & Analysis Engine as shown in the screen shot below:

**Default Standard, Units & Analysis Engine**

Select Default Standard: American ANSI/TIA-222-G-2005

**Units**

Metric  US Customary

**Default Analysis Engine**

Monopoles	TSTower
Lattice - Self Support	TSTower
Lattice - Guyed Mast	Robot

Robot Options ...

**Note:**  
The Units, Design Standard and Analysis Engine you declare in this form will serve as defaults in all newly opened files.

**Set STAAD Paths**

Path to executable:  ...

Path to Input/Output Folder:

**Set GUYMAST Paths**

Path to executable: C:\WEISMAN

Path to Input/Output Folder: C:\WEISMAN.DAT

**Default Path to Section.mdb Database**

C:\Program Files\TSTower ...

Accept Defaults Cancel

## Chapter 4 RESULTS

In this Chapter the printed and viewable output options for the program are explained. After the input data phase is completed, the user chooses **Run** from the main menu. The program performs the wind load calculations and executes the structural analysis. From the main menu the user may choose **Results** and the user chooses one from the following menu options:

- Preliminary Results
- Final Results
- Print
- .DXF Profile

### Preliminary Results

Choosing Preliminary results the following screen is displayed which allows the user to see the different calculated wind pressure and effective projected areas for each of the different load combinations and wind directions.

#### Wind Pressure

The screenshot shows a software window titled "View Preliminary Results" with a table of wind pressure data. The table has columns for Section, Panel, Bot. Elev. (ft), Top Elev. (ft), Kz, Kzt, QzGh (psf), and Ice Thick. (tiz) (in). The data is organized by sections 12, 13, 14, and 15, with each section having multiple panels. The bottom of the window includes dropdown menus for "Load Combination" (set to "Wind Only") and "Wind Direction (Deg)" (set to "0").

Section	Panel	Bot. Elev. (ft)	Top Elev. (ft)	Kz	Kzt	QzGh (psf)	Ice Thick. (tiz) (in)
15	4	295.00	300.00	1.59	1.00	38.13	0.000
	3	290.00	295.00	1.59	1.00	37.99	0.000
	2	285.00	290.00	1.58	1.00	37.85	0.000
	1	280.00	285.00	1.57	1.00	37.71	0.000
14	4	275.00	280.00	1.57	1.00	37.57	0.000
	3	270.00	275.00	1.56	1.00	37.43	0.000
	2	265.00	270.00	1.56	1.00	37.28	0.000
	1	260.00	265.00	1.55	1.00	37.14	0.000
13	4	255.00	260.00	1.54	1.00	36.99	0.000
	3	250.00	255.00	1.54	1.00	36.83	0.000
	2	245.00	250.00	1.53	1.00	36.68	0.000
	1	240.00	245.00	1.53	1.00	36.52	0.000
12	4	235.00	240.00	1.52	1.00	36.36	0.000
	3	230.00	235.00	1.51	1.00	36.20	0.000
	2	225.00	230.00	1.50	1.00	36.03	0.000
	1	220.00	225.00	1.50	1.00	35.87	0.000

This screen shows bottom and top elevation of each section the applied wind pressure and the relevant height factors and ice thickness for each of the load combination and wind directions.

**Wind Area**

View Preliminary Results

Wind Pressure		Wind Area			App. UDL		App. Conc. Loads			Section Weights		
Sec.	Panel	Flat Area (ft <sup>2</sup> )	App. Flat Area (ft <sup>2</sup> )	Round Area (ft <sup>2</sup> )	App. Round Area (ft <sup>2</sup> )	Area Ice (ft <sup>2</sup> )	Solid Ratio	Flat Drag	Round Drag	Flat Dir	Round Dir	Eff. Area (ft <sup>2</sup> )
15	4	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	3	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	2	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	1	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
14	4	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	3	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	2	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	1	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
13	4	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	3	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	2	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	1	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
12	4	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	3	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	2	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73
	1	5.96	0.00	0.00	0.00	0.00	0.24	2.46	0.00	0.80	1.00	11.73

Load Combination: Wind Only      Wind Direction (Deg): 0

This screen shows flat and round areas of the structure and that of the appurtenances included as part of the structure in the calculations. Solidity ratios are also show for each panel and the calculated force coefficients (drag coefficients) for both flat and round members. Also the directionality factors and the total effective wind areas are shown for each of the load combinations and wind directions.

**Appurtenances Uniformly Distributed Loads (UDL)**

The screenshot shows a software window titled "View Preliminary Results" with a table of data. The table has columns for "Wind Pressure", "Wind Area", "App. UDL", "App. Conc. Loads", and "Section Weights". The main data table has columns: "Sec.", "Panel", "Flat Area (ft^2)", "Round Area (ft^2)", "Flat Drag", "Round Drag", "Ka", and "Eff. Area (EPA) (ft^2)". The data is organized by section number (15, 14, 13, 12) and panel number (4, 3, 2, 1). At the bottom, there are dropdown menus for "Load Combination" (set to "Wind Only") and "Wind Direction (Deg)" (set to "0").

Sec.	Panel	Flat Area (ft <sup>2</sup> )	Round Area (ft <sup>2</sup> )	Flat Drag	Round Drag	Ka	Eff. Area (EPA) (ft <sup>2</sup> )
15	4	1.70	0.74	1.50	1.20	0.60	2.06
	3	1.70	0.74	1.50	1.20	0.60	2.06
	2	1.70	0.74	1.50	1.20	0.60	2.06
	1	1.70	0.74	1.50	1.20	0.60	2.06
14	4	1.70	0.74	1.50	1.20	0.60	2.06
	3	1.70	0.74	1.50	1.20	0.60	2.06
	2	1.70	0.74	1.50	1.20	0.60	2.06
	1	1.70	0.74	1.50	1.20	0.60	2.06
13	4	1.70	0.74	1.50	1.20	0.60	2.06
	3	1.70	0.74	1.50	1.20	0.60	2.06
	2	1.70	0.74	1.50	1.20	0.60	2.06
	1	1.70	0.74	1.50	1.20	0.60	2.06
12	4	1.70	0.74	1.50	1.20	0.60	2.06
	3	1.70	0.74	1.50	1.20	0.60	2.06
	2	1.70	0.74	1.50	1.20	0.60	2.06
	1	1.70	0.74	1.50	1.20	0.60	2.06

The appurtenances uniformly distributed loads not included as part of the face are shown on this screen. The window shows the calculated flat and round areas as well as the corresponding force coefficients (drag factors) for each of the load combinations and wind directions.

**Appurtenances Concentrated Loads (UDL)**

Wind Pressure			Wind Area		App. UDL			App. Conc. Loads			Section Weights		
Ant	Desc.	Qty	Mount Desc	Elev. (ft)	CaAc X-Dir E-W (ft <sup>2</sup> )	CaAc Y-Dir N-S (ft <sup>2</sup> )	X-Force E-W (Kips)	Y-Force N-S (Kips)	Z-Force (Kips)	M-x (Kipsft)	M-y (Kipsft)	M-z (Kipsft)	
1	TA-803-60	1		300.00	0.00	-6.75	0.00	-0.26	-0.04	-0.10	0.00	0.00	
2	TA-803-60	1		300.00	0.00	-4.80	0.00	-0.18	-0.04	0.05	0.09	-0.47	
3	TA-803-60	1		300.00	0.00	-4.80	0.00	-0.18	-0.04	0.05	-0.09	0.47	
4	HP6	1		290.00	0.00	-40.35	0.00	-1.53	-0.28	-0.83	0.00	0.00	
5	SRL-480	1		305.00	0.00	-2.87	0.00	-0.11	-0.03	-0.08	0.00	0.00	
1	Pnt. Load			0.00	0.00	-45.00	0.00	-0.92	-1.25	0.00	0.00	0.00	
2	Pnt. Load			298.00	0.00	-40.00	0.00	-1.53	0.00	0.00	0.00	0.00	
4	Torsion			275.00	0.00	-32.45	0.00	-1.22	-1.12	0.00	0.00	0.00	

Load Combination: Wind Only      Wind Direction (Deg): 0

The appurtenances calculated concentrated loads are shown on this screen. The window shows the calculated flat and round areas in the direction of each axis and the corresponding forces and moments in the three axes. This value can be selected for each of the load combinations and wind directions.

**Section Weights**

The screenshot shows a software window titled "View Preliminary Results" with a blue header and a close button. The window contains a table with the following data:

Sec.	Legs (lbs)	Bracing (lbs)	Sec. Bracing (lbs)	Int. Bracing (lbs)	Total Section (lbs)
1	583.8	794.3	0.0	0.0	1378.1
2	583.8	794.3	0.0	0.0	1378.1
3	583.8	794.3	0.0	0.0	1378.1
4	583.8	794.3	0.0	0.0	1378.1
5	583.8	794.3	0.0	0.0	1378.1
6	583.8	794.3	0.0	0.0	1378.1
7	583.8	794.3	0.0	0.0	1378.1
8	583.8	794.3	0.0	0.0	1378.1
9	583.8	794.3	0.0	0.0	1378.1
10	583.8	794.3	0.0	0.0	1378.1
11	583.8	794.3	0.0	0.0	1378.1
12	583.8	794.3	0.0	0.0	1378.1
13	583.8	794.3	0.0	0.0	1378.1
14	583.8	794.3	0.0	0.0	1378.1
15	583.8	794.3	0.0	0.0	1378.1
Total:	8757.0	11915.2	0.0	0.0	20672.2


The section weights with divisions for Legs, Bracing, Secondary Bracing, Internal Bracing and Totals are shown in this grid.

### ***Final Results***

Choosing final results the following screen is displayed which allows the user to view the results of the analysis for either the maximum envelope or any of the different load combinations and wind directions.


### **Legs**

The assessment of the tower legs is shown in tabular form and graphical format by plotting the tensile or compression forces versus the corresponding capacities of the member. The diagram is refreshed based on the selection of either the tensile or compression columns.



### Diagonals

The assessment of the tower diagonals is shown in tabular form and graphical format by plotting the tensile or compression forces versus the corresponding capacities of the member. The diagram is refreshed based on the selection of either the tensile or compression columns. Similar results can be viewed for tower horizontals from the next tab.




Also, on the bottom of the screen, the user may select the load combination for which results are to be displayed. Load combinations selected from the analysis

menu are shown in the load combination list. Specific wind direction may be chosen or simply the envelope of the maximum values.

### Results Summary

The user may view the summary of the assessment based on colored contours of the tower. The contours summarize the results depending on the governing either compressive or tensile forces.




Also, on the bottom of the screen, the user may select the load combination for which results are to be displayed. Load combinations selected from the analysis menu are shown in the load combination list. Specific wind direction may be chosen or simply the envelope of the maximum values.



### Tower Displacements

The user may view the tower displacement and rotations in the three directions from the **Disp.** Tab.



The displacements can also be viewed for the maximum envelope or any of the load combinations or wind directions.

### Antenna Displacements


On this screen, the user can see the antenna number (for this example, the tower has 1 antenna at 100 ft. elevation), and the elevation at each antenna, displacements in the orthogonal three directions, rotations and twist.

Legs	Diag	Horiz	Disp	Rot	Summary	Found	Disp	Twist	Guys
Ant.	Descript.	Elev. (ft)	N-S disp (in)	W-E disp (in)	Vert. disp (in)	N-S rot (Deg)	W-E rot (Deg)	Twist (Deg)	Allow. (Deg)
1	TA-803-60	300.0	30.0	-23.0	-1.1	-0.40	-0.30	0.31	0.00
2	TA-803-60	300.0	30.0	-23.0	-1.1	-0.40	-0.30	0.31	0.00
3	TA-803-60	300.0	30.0	-23.0	-1.1	-0.40	-0.30	0.31	0.00
4	HP6	290.0	29.2	-22.4	-1.1	-0.38	-0.29	0.30	1.48
5	SRL-480	305.0	30.2	-23.2	-1.1	-0.40	-0.30	0.31	0.00

Load Combination: Max Envelope | Wind Direction (Deg): Max | Tower View | Section View

### Guys Assessment

This screen shows the assessment of the guys for each guy level as well as the assessment of the Torsion Resistors (if applicable).



Also, on the bottom of the screen, the user may select the load combination for which results are to be displayed. Load combinations selected from the analysis menu are shown in the load combination list. Specific wind direction may be chosen or simply the envelope of the maximum values.

## Printout

From the main menu, click on **Results**, and the following screen will be displayed. From this screen the user may choose the required printout sections by clicking on the corresponding check box.

**View and Print**

Printing Schedule

<u>Input Data</u>	<u>Output Data</u>	<u>Diagrams</u>
<input type="checkbox"/> Project Data	<input type="checkbox"/> Wind Load Data	<input type="checkbox"/> Profile
<input type="checkbox"/> Structure Data	<input type="checkbox"/> Structure Displ. Data	<input type="checkbox"/> Displacements
<input type="checkbox"/> Guy System Data	<input type="checkbox"/> Antenna Displ. Data	<input type="checkbox"/> Leg Load Compression
<input type="checkbox"/> Antenna Data	<input type="checkbox"/> Assessment Data	<input type="checkbox"/> Leg Load Tension
<input type="checkbox"/> Tx Line Data	<input type="checkbox"/> Section Capacities	<input type="checkbox"/> Diag. Load Compression
<input type="checkbox"/> Ladder Data	<input type="checkbox"/> Guy Tension Data	<input type="checkbox"/> Diag. Load Tension
<input type="checkbox"/> Point Load Data	<input type="checkbox"/> Base Reaction Data	<input type="checkbox"/> Horiz. Load Compression
<input type="checkbox"/> Guy Tension Chart	<input type="checkbox"/> Anchor Load Data	<input type="checkbox"/> Horiz. Load Tension
	<input type="checkbox"/> Torsion Resistor Assessment Data	<input type="checkbox"/> Mast Moment & Shear (N-S)
		<input type="checkbox"/> Mast Moment & Shear (E-W)

Note that for analysis including several load combinations and different wind directions as well the user has the option to select the required sections for printing and also the desired wind directions. This may result in a relatively large number of pages in the printout. By choosing the profile, the program prints a simple profile on which the project data, design specification, base reactions and tower geometry are printed in a graphical format.


## Export Profile

Select sub-menu “**Export Profile (\*.dxf)**” from main menu “**Results**”.  
Following screen will be displayed.



Click on “**Export DXF file**” button.

If you have selected DXF viewer you will find additional button “**View Profile**” as shown below.





## Chapter 5 DATABASE MANAGEMENT

The program uses "USER" Antenna database for selection of the antennas, mounts and TX Lines.

Apart from the "USER" database there is "MASTER" database (not to be modified) and "REMOTE" database or databases, which can be placed in commonly accessed server and thus shared by different users typically within the same organization.

The "USER" and "REMOTE" databases can be modified by the users.

### Antennas Database

From the main menu, click on **Database Management** and **Antennas** submenu. Following screen will be displayed.

**Antenna Database Management**

Dish Antennas    Non-Dish Antenna Manufacturers    Non-Dish Antennas    TX Lines

39 records.


ID	Manufacturer	Microwave Code	Shielded Type	Catalogue Name	Description	Radome	Diameter (ft)
1	Andrews	<input checked="" type="checkbox"/>	Shielded	HP2	M/W Shielded	<input checked="" type="checkbox"/>	2.001
2	Andrews	<input checked="" type="checkbox"/>	Shielded	HP4	M/W Shielded	<input checked="" type="checkbox"/>	4.003
3	Andrews	<input checked="" type="checkbox"/>	Shielded	HP6	M/W Shielded	<input checked="" type="checkbox"/>	6.004
4	Andrews	<input checked="" type="checkbox"/>	Shielded	HP8	M/W Shielded	<input checked="" type="checkbox"/>	8.005
5	Andrews	<input checked="" type="checkbox"/>	Shielded	HP10	M/W Shielded	<input checked="" type="checkbox"/>	10.007
6	Andrews	<input checked="" type="checkbox"/>	Shielded	HP12	M/W Shielded	<input checked="" type="checkbox"/>	12.008
7	Andrews	<input checked="" type="checkbox"/>	Shielded	HP15	M/W Shielded	<input checked="" type="checkbox"/>	14.993
8	Andrews	<input checked="" type="checkbox"/>	Focal Plane	FP4	M/W Focal Plane	<input checked="" type="checkbox"/>	4.003
9	Andrews	<input checked="" type="checkbox"/>	Focal Plane	FP6	M/W Focal Plane	<input checked="" type="checkbox"/>	6.004
10	Andrews	<input checked="" type="checkbox"/>	Focal Plane	FP8	M/W Focal Plane	<input checked="" type="checkbox"/>	8.005
11	Andrews	<input checked="" type="checkbox"/>	Focal Plane	FP10	M/W Focal Plane	<input checked="" type="checkbox"/>	10.007
12	Andrews	<input checked="" type="checkbox"/>	Focal Plane	FP4	M/W Focal Plane	<input type="checkbox"/>	4.003

Print    Note: This table is non-editable (read only).

Exit    Database: USER    Change Database

The first group "Dish Antennas" is non-editable (read only), as it covers practically all types and sizes of Microwave Dish Antennas.

Non-Dish Antenna Manufacturers



User can add new manufacturers. Such action will create an empty table and the user will then add records to such table. Deletion of manufacturer will cause removal of the manufacturer name from the list as well as deletion of a table of non-dish antennas associated with the manufacturer. Default database is "USER" but any other "REMOTE" database can be selected (if present) and then the modifications are performed in the selected database. Once such "Remote" database is created and located remotely (on a server) other users can synchronize their local "USER" database with the "REMOTE".

Non-Dish Antennas

**Antenna Database Management**

Dish Antennas    Non-Dish Antenna Manufacturers    **Non-Dish Antennas**    TX Lines

Table: ALLGON - 10 records.

	Catalogue Name	Description	Height (ft)	Width (ft)	Depth (ft)	Frontal Area (ft <sup>2</sup> )	Frontal Area Iced 10mm
▶	7145.21	CITY PANEL 105 deg	0.984	0.984	0.427	1.001	1.130
	7145.22	CITY PANEL 105 deg	1.969	0.984	0.427	1.981	2.174
	7145.23	CITY PANEL 105 deg	2.953	0.984	0.427	2.960	3.229
	7145.24	CITY PANEL 105 deg	3.937	0.984	0.427	3.950	4.284
	7145.26	CITY PANEL 105 deg	5.906	0.984	0.427	6.146	6.383
	7145.48	CITY PANEL 105 deg	7.546	0.984	0.427	7.901	8.148
	7183.15	PCS	3.281	0.459	0.164	3.057	3.563
	7184.14	PCS	4.265	0.459	0.164	3.057	3.541
	7184.15	PCS	4.265	0.459	0.164	3.057	3.541
	7185.15	PCS	3.281	0.853	0.164	4.155	4.575

Select Table: ALLGON    Edit Record    Add Record    Delete Record    Print

Exit    Database: USER    Change Database

To edit or add record for selected table click on "Edit Record" or Add Record" buttons. Following screen will be displayed.

**Edit Non-Dish Antenna, table: ALLGON**

Catalogue Name: 7145.21

Description: CITY PANEL 105 deg

Height: 0.984 (ft)    Weight: 4.41 (lbs)

Width: 0.984 (ft)    Weight Iced 10 mm (1/2"): 11.01 (lbs)

Depth: 0.427 (ft)    Weight Iced 50 mm (2"): 37.44 (lbs)

Frontal Area (EPA)N: 1.001 (ft<sup>2</sup>)    Round

Frontal Area Iced 10 mm (1/2"): 1.130 (ft<sup>2</sup>)

Frontal Area Iced 50 mm (2"): 1.776 (ft<sup>2</sup>)

Lateral Area (EPA)L: 0.441 (ft<sup>2</sup>)

Lateral Area Iced 10 mm (1/2"): 0.538 (ft<sup>2</sup>)


Lateral Area Iced 50 mm (2"): 1.023 (ft<sup>2</sup>)

Effective Projected Area (EPA) Normal (Frontal) or Lateral includes all applicable drag factors or force coefficients but does not include height factors.


Accept    Cancel

Changes of entries will become effective after "Accept" button is clicked.

TX Lines




To add or edit a record click on “Add new Record” or “Edit Record” buttons respectively. Following screen will be displayed.



Changes of entries will become effective after “Accept” button is clicked.


## Mounts

From the main menu, click on **Database Management** and **Mounts** submenu. Following screen will be displayed.



User may add new manufacturers (as is the case with Non-Dish Antennas) or delete them.

## Antenna Mounts




To add or edit a record click on "Add new Record" or "Edit Record" buttons respectively. Following screen will be displayed.

Catalogue Name:	none	
Description:	n/a	
Height :	0.000 (ft)	Weight : 0.00 (lbs)
Width :	0.000 (ft)	Weight Iced 10 mm: 0.00 (lbs)
Depth :	0.000 (ft)	Weight Iced 50 mm : 0.00 (lbs)
Frontal Area :	0.000 (ft <sup>2</sup> )	Round <input checked="" type="checkbox"/>
Frontal Area Iced 10 mm:	0.000 (ft <sup>2</sup> )	
Frontal Area Iced 50 mm:	0.000 (ft <sup>2</sup> )	
Lateral Area :	0.000 (ft <sup>2</sup> )	
Lateral Area Iced 10 mm:	0.000 (ft <sup>2</sup> )	
Lateral Area Iced 50 mm:	0.000 (ft <sup>2</sup> )	


Perform the editing and press "Accept" button to update or "Cancel" otherwise.

### Guys Database

From the main menu, click on **Database Management** and **Mounts** submenu. Following screen will be displayed.



When "Edit Record" button is clicked following form appears:



When "Add Record" button is clicked following form shows:


Field Label	Unit
Metric Description	
Imperial Description	
Diameter	(in)
Breaking Strength	(Kips)
Unit Mass	(lbs/ft)
Metallic Area	(in <sup>2</sup> )
Modulus of Elasticity	(ksi)
Thermal Coefficient	(/Deg. F)

After the data is entered for the new addition clicking on "Accept" button will add the new guy to the table. "Cancel" button should be used to ignore the entries (new Guy will not be added).

### Database Setup

From the main menu, click on **Database Management** and **Database Setup** submenu.

Following screen will be displayed.




New remote database(s) can be created in three different ways:

“Populate from Master Database” – new “remote” database will be replicated from “Master Database” and then user will indicate the location of the new database – screen showing selection of “drives” and “folders” will be displayed.

Populate from Master Database

“Populate from User database” – new “remote” database will be replicated from “User Database” and then user will indicate the location of the new database – screen showing selection of “drives” and “folders” will be displayed.

“Get from Remote Location” this action will prompt you to select existing “remote” database not linked to you computer so far.



Once you selected the “remote” database it will be displayed in the “Remote Database Location” grid and you will have access to it via Database Management for Antennas or Mounts.

“Check Integrity” will perform the comparison of the records between selected remote database and “Master Database” and display differences.

“Delete Link” will remove a link between selected “remote” database and the program (such database will not be accessible to you).

Synchronize Databases – instructions as shown on attached screenshot.

